

i NSTRUCTION

for DIGITAL LOCK



P200N

Quality reputed worldwide ———
diplomat SAFE 

How to operate Private Security Box P200?

- Using a screw driver, remove the bolt in the left side of the button plate and pull it front and load batteries in battery compartment (1.5V AA Alkaline 4 pcs). Then, **REAdy** appears on LED.



1. HOW TO OPEN DOOR ?

The factory initial code of the safe is **1 2 3 4 5 6**.

Step 1 : Press the initial six digit code buttons consecutively.
Then, the door projects out and opens.

1 → **2** → **3** → **4** → **5** → **6**

(OPEnEd appears on LED)

- If a wrong code entered, **FAILED** appears on LED.
- If wrong codes entered over 5 times, EDL gets frozen and doesn't work.
- After 3 minutes in paralysis, EDL recovers in normal state.

2. HOW TO CLOSE DOOR ?

Step 1 : Keeping door closed,

Step 2 : Press **C** button. (CLOSEd appears on LED)

- ▲ **Caution** : Without keeping door closed, if **C** button is pressed, the motor doesn't return the boltwork into the housing leaving door open. (FAILED appears on LED)

3. HOW TO ENTER YOUR PERSONAL CODE ?

Step 1 : Decide 6 digit code and press the code buttons consecutively.
(Code appear on LED whenever each button pressed)

Step 2 : Press **E** button.
(The entered code flickers three times and EnTERd follows on LED)

Ex) In case of your code 7 7 8 8 9 9, press the buttons

778899E.

▲ Caution : Please confirm if your code correctly entered.

7→7→8→8→9→9

4. HOW TO SET DATE AND HOUR ?

★ For recording function, you have to set date and hour.

★ Time (date and hour) can be set with Time Set Button on the backside of EDL.

★ For example, to set January 01 2007 12:30

Step 1 : Press Time Button (T) on the back of door (1-00)

Step 2 : Press the last two digits of year (1-07)

Step 3 : Press **E** button (2-00)

Step 4 : Press Month button (2-01)

Step 5 : Press **E** button (3-00)

Step 6 : Press Date button (3-01)

Step 7 : Press **E** button (4-00)

Step 8 : Press Hour button (4-12)

Step 9 : Press **E** button (5-00)

Step 10 : Press Minute button (5-30)

Step 11 : Press **T** button (LED turns off)

★ In short, press the buttons in turn as indicated hereunder.

T(Time Button) → 07(Year) → E → 01(Month) → E → 01(Date)

E → 12(Hour) → E → 30(Minute) → T(Time Button)

5. BATTERY CHANGE ? (1.5V AA Alkaline 4 pcs)

■ When to change batteries ?

When opening door, if the door is not opened in spite of the appearance of *OPEnEd* on LED, it indicates that the battery power is not strong enough to actuate the boltwork. In this case, 4 batteries should be replaced with new ones all together.

Step 1 : Unscrew the bolt in the left side of the EDL plate and pull it to remove.

Step 2 : Replace 4 batteries with new ones. (1.5V AA Alkaline 4 pcs)

Step 3 : Assemble the EDL plate and secure it with a bolt,

- Even though the batteries are completely exhausted, the entered code never erases.
- Life span of the batteries is 18 months in case of daily openings 3 time.
- After replacement of batteries, data and time must be reset.



1583-4 SONGJUNG-DONG GANGSEO-GU BUSAN, KOREA TEL (82 51) 831-4400 FAX (82 51) 831-4409

Email : info@dsafe.co.kr www.dsafe.kr

● To improve products constantly, Diplomat Safe reserves the right to alter the specifications without prior notice.
Printed in Korea, July 02, 2007 REV. 1